

# Quick Start Guide - ProLogic Series L02-L90



Congratulations on the purchase of your new SECURAM ProLogic Series Safe Lock! This Quick Start guide will help you set up your ProLogic for use. **Note: All programming must be completed with the safe door open. The safe lock system is powered by (1) 9V alkaline battery. Duracell or Energizer brands are recommended.**

The ProLogic comes with (2) default codes:  
ID00 or the Super Code is set to 111111  
ID01 or the Manager Code is set to 123456  
It is recommended to change both codes to unique codes immediately.

## Step 1: Decide on Code Length and Number of Users

The ProLogic has a maximum of 30 available user codes - 2 Manager codes and up to 28 User Codes. In addition you can set the code length as either 6 digits or 8 digits. By default, the ProLogic entry pads are set with P/W L - 6; Users 10.


Number of users and code length should be decided before any other programming takes place. This operation must be performed with the safe door open with access to the back of the lock, as a mechanical reset must be performed during this programming sequence.

There are three different modes in this regard as follows:

- P/W L = 6 digits; Users = 10 (default mode)
- P/W L = 8 digits; Users = 30
- P/W L = 6 digits; Users = 30

Select the desired mode as follows:

Press the Menu/OK button. The LCD screen will display "Select Menu", press the ▼ button, until you see the menu selection "System Menu". Press OK. Enter the Super Code or Manager Code; the display will show "IDXX Verified" and then "Select Menu" will appear. Press the ▼ button, until you see the menu selections related to Code Length and User Codes and press Menu/OK to select.




Note: if you select P/W L = 8; Users = 30, then the resulting default codes would be as follows:  
ID00 or the Super Code is set to 11111100  
ID01 or the Manager Code is set to 12345600

## Step 2: Change the Default Codes (P/W L = 6)


Press the Menu/OK button. The LCD screen will display "Select Menu", press the ▼ button, until you see the menu selection "System Menu". Press OK

Enter the default Super Code 111111; display will show "ID00 Verified" and then "Select Menu" Screen will appear.


Press the ▼ button, until you see the menu selection "Change Code".




Press Menu/OK



Enter a 6 digit code



Repeat 6 digit code




ID00 Code is now saved


Follow the same procedure to change the Manager Code. Use the default Manager Code 123456 .

## Step 3: To Open Lock

Just enter a valid code:



Enter valid digit code



Valid code will be verified and the lock will open for 6 seconds, after which it will automatically relock.

## Step 4: Enrolling a New User Code

With the ProLogic you can add up to 28 User Codes. Follow these steps:

Press the Menu/OK button. The LCD screen will display "Select Menu", press the ▼ button, until you see the menu selection "System Menu". Press OK.

Enter the Super Code or Manager Code; the display will show "IDXX Verified" and then "Select Menu" will appear.

Press the ▲ button, until you see the menu selection "Enroll New User".

Press Menu/OK.

Continued on next page...

# Quick Start Guide - ProLogic Series L02-L90



## Step 4 - Continued

The LCD will display as follows:

	Press Menu/OK here.
	Select the ID # of the desired position by pressing the ▲ or ▼ buttons. ID03-30 are User
	ID02 has management functions.
	Enter a unique code (6 or 8 digits per your settings).
	Repeat this unique code.
	The User code is now saved.

Repeat these steps to add other Users.

## Step 5: Single or Dual Mode

The ProLogic can operate in either single mode, where the entry of one code opens the lock; or dual mode, where the entry of two codes is required to open the lock.

By default the ProLogic is in Single Mode.

Follow these steps to change modes:

Press the Menu/OK button. The LCD screen will display "Select Menu", press the ▼ button, until you see the menu selection "System Menu". Press OK. Enter the Super Code or Manager Code; the display will show "IDXX Verified" and then "Select Menu" will appear. Press the ▼ button, until you see the menu selection "Enable Dual Mode".

	Press Menu/OK. Dual Mode is now enabled.
--	---

ID00, ID01 and ID02 are Dual Mode Override Codes by default.

## Step 6: Set/Cancel Time Delay

The ProLogic can be programmed with a Time Delay setting.

Follow these steps to set a Time Delay value: Press the Menu/OK button. The LCD screen will display "Select Menu", press the ▼ button, until you see the menu selection "System Menu". Press OK. Enter the Super Code or Manager Code; the display will show "IDXX Verified" and then "Select Menu" will appear. Press the ▼ button, until you see the menu selection "Set/Cancel Time Delay".

	Press Menu/OK
--	---------------

	Press the ▲ button to set the desired Time Delay value. (0-99 minutes)
--	--

Once the Time Delay value has been set, you will be required to set the Time Window value. This is the length of time, after Time Delay expires, that the User will have to enter his code again to open the lock.

	Press the ▲ button to set the desired Time Window value and Press Menu/OK.
--	--

Time Delay has now been set. All User codes must now abide by Time Delay.

By default ID00, ID01 and ID02 have Time Delay Override capability. This can be changed in the TDO User ID menu.

## Step 7: Register your ProLogic Safe Lock

Your safe lock is eligible for a 12 month warranty covering product defects. Within 90 days of purchasing your safe/safe lock, please visit our website to register your product.

Please visit [www.securamsys.com/warranty](http://www.securamsys.com/warranty) and look for the button entitled "Register My Warranty".

For technical support, contact your safe provider or SECURAM Systems at 805-988-8088.

For a full set of Operating Instructions, visit our website at [www.securamsys.com](http://www.securamsys.com)